



- Site Boundary
- Turbine
- Permanent Met Mast
- Substation
- New Cut Track
- New Floating Track
- Existing Track for Construction Only
- Existing Track to be Reinstated
- Existing Track to be Reused
- Borrow Pit Working Area
- Borrow Pit Search Area
- Construction Compound
- Laydown Area
- Operations Building
- Potential Groundwater Dependent Terrestrial Ecosystems (GWDTEs)
- Moderately GWDTE
- Highly GWDTE
- 100 m Buffer for excavations < 1 m
- 250 m Buffer for excavations > 1 m

Note: In Accordance to SEPA Guidance Note 4.
However, as explained in chapter, not all habitat types listed as GWDTE are always groundwater fed.

Scale 1:15,000 @ A3
0 250 500 Meters



Figure 10.4
Groundwater Dependent
Terrestrial Ecosystems

Tangy IV Wind Farm
EIA Report